

Slider control with switch.

Suitable for resistive loads, incandescent lamps and halogen lamps 230Vac. Usable for class I and II equipments.

Lighting indicator of brightness level. Built-in fuse: T 2,5A H / 250V.

Provided with ground clamp. Plastic case for domestic series.

A



Rev. v.1.10 03/10/2017

PRODUCT TO BE DISPOSED DIFFERENTLY FROM URBAN WASTE MADE IN ITALY

<u></u>				
CODICE CODE	FUNZIONE FUNCTION	COLORE COLOR	RESISTIVO RESISTIVE	RESISTIVO RESISTIVE
			Lampade ad Incandescenza	Lampade Alogene
			Incandescent Lamps	Halogen Lamps
			230Vac	230Vac
DLP1013SN	DIMMER	NERO BLACK	60÷300W	60÷300W
DLP1013SB		BIANCO WHITE		
DLP1013SA		TRASPARENTE TRASPARENT		


TECHNICAL FEATURES

Input voltage range: 220-240Vac Input frequency: 50-60Hz

ATTENTION:

The installation of the product must be followed by gualified personnel.

If the product is used for purposes other than the original ones or if it is connected incorrectly, LEF Lighting S.R.L. will not accept any responsibility for damages caused.





INSTRUCTIONS Code: DLP1013SN / DLP1013SB /DLP1013SA FLOOR INDEPENDENT DIMMER

ASSEMBLING INSTRUCTIONS (FIG. 1)

Unscrew the closing screw A.

Take out the cover C.



Unscrew the screw D of the cord anchorage E.


Strip the cable to be connected respecting the quotes indicated.

Connect supply cable to the terminals $\boldsymbol{\mathsf{L}}$ and $\boldsymbol{\mathsf{N}}$ of the electronic card.

Connect lamp cable to the terminals identified by symbol \nearrow and N of the electronic card.

Mount cord anchorage E using the screw D.

Mount cover C, screwing the screw A.



INSTRUCTIONS Code: DLP1013SN / DLP1013SB /DLP1013SA FLOOR INDEPENDENT DIMMER

ASSEMBLING INSTRUCTIONS (FIG. 1)

Unscrew the closing screw A.

Take out the cover C.

Unscrew the screw D of the cord anchorage E.

Strip the cable to be connected respecting the quotes indicated.

Connect supply cable to the terminals $\boldsymbol{\mathsf{L}}$ and $\boldsymbol{\mathsf{N}}$ of the electronic card.

Connect lamp cable to the terminals identified by symbol and **N** of the electronic card.

Mount cord anchorage E using the screw D. Mount cover C, screwing the screw A.

